






allow the spur gear to slip during normal operation).

Visite la página TRAXXAS.com/manuals para descargar el instructiones en su idioma.

Auf TRAXXAS.com/manuals können Sie anleitung in Ihrer Sprache downloaden.



TRAXXAS.COM ____

KC2513-R02 Rev 170523